

ISTRUZIONI PER UNA CORRETTA INSTALLAZIONE, USO E MANUTENZIONE

Disegn: Area 17 + Emiliana Martinelli

AVVERTENZE

Dim: Ø 40 H12

Le seguenti istruzioni devono essere seguite per una corretta installazione del prodotto, e servono a garantire la vostra sicurezza. È necessario conservarle per una successiva consultazione. Questo foglio deve essere a disposizione anche di chi ne avrà la manutenzione.



L'apparecchio è adatto al montaggio su superfici normalmente infiammabili.

Apparecchio solo per interni (non protetto all'acqua).

L'apparecchio è conforme alle norme e alle direttive vigenti.

Simbolo per lo smaltimento dell'apparecchio (vedere SMALTIMENTO DELL'APPARECCHIO RAEE).

INSTALLAZIONE


- Togliere tensione all'impianto prima dell'installazione;
- Separare la borchia (1) dalla base a plafone (2) allentando il pomello (3);
- Fissare la basetta (2) con adeguati tasselli ad un interasse come indicato in figura;
- Passare il cavo di alimentazione della rete dal passacavo (4);
- Collegare i cavi di alimentazione alla morsetteria (5); il cavo di terra deve essere collegato al morsetto contrassegnato dal simbolo ⊕;
- Stabilire la lunghezza del cavo di alimentazione dell'apparecchi, collegarlo alla morsetteria (5) e bloccarlo con il ponticello (6);
- Stabilire la lunghezza del cavo d'acciaio e bloccarlo con il morsetto (7);
- Chiudere la borchia (2) col disco (1) avvitando il pomello (3);

NOTE SUPPLEMENTARI

- Durante il cablaggio si consiglia di passare il cavo di alimentazione rosso all'interno del pomello sul braccio;
- E' possibile regolare l'inclinazione dell'apparecchio ruotando il corpo rispetto al braccio;

CAUTELE DA ADOTTARE DURANTE L'USO DELL'APPARECCHIO

- Durante la manutenzione (per sostituzione lampada o pulizia) togliere tensione e lasciar raffreddare l'apparecchio;
- Per la pulizia usare solamente un panno asciutto;
- Ogni uso differente da quanto mostrato non è consentito;
- Per la vostra sicurezza non modificare l'apparecchio; richiedete al costruttore o al venditore per le parti di ricambio originali;
- Per lo smaltimento utilizzare le zone di raccolta appositamente destinate dalle amministrazioni comunali.



INSTRUCTIONS FOR A CORRECT INSTALLATION, USE AND MAINTENANCE

Disegn: Area 17 + Emiliana Martinelli

WARNINGS

Dim: Ø 40 H12

Following instructions must be applied for the corrected installation, use and maintenance of the product, and serve to guarantee your safety. These instructions have to be kept for future reference, and must be to disposition also of who will have the maintenance. In case of doubt, please consult a qualified electrician.



The luminaire is suitable for use on normally flammable surfaces

Internal use only (not splash-proof).

The luminaire stands the directives and the standards in law.

Symbol for the disposal of the equipment (see WEEE or equivalent legislation in your country)

INSTALLATION

- Switch off the system before installation;
- Separate the stud (1) from the base surface-mounted (2) by loosening the knob (3);
- Fasten the mounting plate (2) with dowels appropriate to a wheelbase as shown in the figure;
- Pass the power cord of the network from the cable gland (4);
- Connect the power cables to the terminal block (5); the ground wire must be connected to the terminal marked by the symbol ⊕;
- Determine the length of dell'apparecchi power cable, connect it to the terminal block (5) and secure it with the jumper (6);
- Determine the length of the steel cable and lock it with the clamp (7);
- Close the stud (2) with the disc (1) by turning the knob (3);

ADDITIONAL NOTES

- When wiring it is recommended to move the red power cable inside the knob on the arm;
- And 'possible to adjust the inclination of the device by rotating the body relative to the arm;

CAUTIONS

- Before the maintenance (for cleaning or relamping) switch off the mains supply; let the luminaire cool down;
- For cleaning use only a dry cloth;
- Each incorrect use different from showed is not allowed;
- For your safety do not modify the luminaire; ask to the manufacturer (or the vendor) for the original spare parts;
- Use the right collecting area reserved by the local government for the discharge of the luminaire.

