



ISTRUZIONI PER UNA CORRETTA INSTALLAZIONE, USO E MANUTENZIONE

**AVVERTENZE**

Le seguenti istruzioni devono essere seguite per una corretta installazione del prodotto, e servono a garantire la vostra sicurezza. È necessario conservarle per una successiva consultazione. Questo foglio deve essere a disposizione anche di chi ne avrà la manutenzione. In caso di dubbio interpellare un elettricista qualificato.




- Apparecchio adatto al montaggio su superfici normalmente infiammabili.
- Apparecchio di Classe I.
- Apparecchio solo per interni (non protetto all'acqua).
- Apparecchio conforme alle norme e alle direttive vigenti.
- Simbolo per il corretto smaltimento dell'apparecchio (RAEE).

**INSTALLAZIONE**

- Togliere tensione all'impianto prima dell'installazione;
- Smontare i 3 pomelli cromati (a) vedi (fig.1) e togliere il diffusore (b);
- Inserire le lampade rispettando il tipo e la potenza indicati sull'apparecchio; spingere a fondo l'attacco della lampada nel portalampada (e) e sui 2 supporti (vedi fig. 5). Inserire il diffusore (b) e riavvitare i 3 pomelli (a);
- Fissare i bloccafuni (d) al soffitto (vedi Figura 4), alle distanze come nella fig.6. Nel bloccacavo passante per la borchia (vedi fig. 7) , dovrà, collegare i cavi di alimentazione (f) al morsetto; facendolo passare dal foro predisposto; il conduttore di terra del cavo di collegamento se trasparente è comunque riconoscibile dal filo distintivo interno giallo-verde;
- Fissare la basetta della borchia (g) al soffitto con l'interasse indicato nella fig. 8;
- Chiudere borchia una volta regolata l'altezza;
- Regolare le 2 rimanenti bloccafuni all'altezza desiderata.

**CAUTELE DA ADOTTARE DURANTE L'USO DELL'APPARECCHIO**

- Durante la manutenzione (per sostituzione lampada o pulizia) togliere tensione e lasciar raffreddare l'apparecchio;
- Per la pulizia usare solamente un panno asciutto; per la pulizia del diffusore è possibile usare un panno appena inumidito. Lasciar asciugare prima di ridare tensione;
- Ogni uso differente da quanto indicato non è consentito;
- Per la vostra sicurezza non modificare l'apparecchio; richiedete al costruttore o al venditore per le parti di ricambio originali.



INSTRUCTIONS FOR A CORRECT INSTALLATION, USE AND MAINTENANCE

**WARNING**

The following instructions must be observed for correct product installation and aim to ensure user safety. Keep them for future reference. This sheet must also be provided to the individuals in charge of maintenance. If in doubt, please seek the advice of a qualified installer.



- The appliance can be installed on normally inflammable surfaces.
- Class I appliance.
- Appliance for indoor use only (not protected against water).
- Equipment complies with current standards and regulations.
- Symbol for the correct disposal of appliance (WEEE).

**INSTALLATION**

- Disconnect power to the lamp before installation;
- Unscrew the 3 chromed knobs (a) see fig.1 and remove the diffuser (b)
- Insert the bulbs in compliance with the type and power indicated on the appliance; push the bulb attachment completely in the bulb holder (e) and 2 supports (see fig.5) . Insert the diffuser (b) and screw the three knobs (a);
- Fix the cable holders (d) to the ceiling (see fig. 4), with the measurements as in fig.6. With the holder that passes through cup, there will have to be connected the supply cable on the terminal (f), letting it pass through the proper hole; ; the earthing of the connection cable if transparent is however recognisable by the distinct yellow-green inner wiring.
- Fix the base of the cup (g) to the ceiling with two screws with the interaxial distance shown in (fig.8);
- Close the cup once the height has been adjusted.
- Regulate the remaining 2 cable holders to the desired height.

**PRECAUTIONS TO TAKE WHILE USING THE APPLIANCE**

- Disconnect power before maintenance operations (to replace the bulb or for cleaning purposes); let the appliance cool down;
  - Clean using a dry cloth; clean the diffuser in Plexiglas using a damp cloth; Leave to dry before reconnecting power;
  - All use, other than that indicated, is forbidden;
- For safety reasons, do not modify the appliance; contact the manufacturer or retailer for any necessary replacement parts.

